

## **Corral Farm Transfer Station Rules and Regulations - Commercial Deliveries**

The transfer station accepts commercial deliveries of Municipal Solid Waste (MSW) as defined by its operating permit and Fauquier County procedures. To maintain safe and efficient working conditions, residential deliveries are approved by special exception only.

### **General Regulations**

All individuals entering the Corral Farm Waste Management Facility must conduct themselves in a courteous and orderly manner, and follow the oral/written instructions of County personnel.

The maximum speed limit at the Corral Farm facility is 15 miles per hour. Restricted and congested areas, time of day, and certain weather conditions require drivers to lower speeds to maintain safe conditions.

All facility areas are non-smoking.

Scavenging of materials is forbidden.

All persons and vehicles entering the Corral Farm facility do so at their own risk. Fauquier County assumes no liability for damages to vehicles or injuries while at the facility. Any accident or injury must be reported immediately to a facility supervisor.

All commercial vehicles are subject to random waste inspection by County personnel.

MSW generated outside of Fauquier County is banned from the Corral Farm facility.

Only permitted and County-approved waste streams may be delivered to the transfer station. At County discretion, any delivery of unauthorized waste subjects the delivery company to waste removal, additional administrative, disposal and environmental clean-up fees, and may be reported to regulators for follow-up investigation.

### **Commercial Vehicle Regulations**

All commercial vehicles delivering MSW to the transfer station must have an operating back-up alarm.

Vehicles will maintain a distance between 15-25 feet from the tipping floor push wall when dumping.

Minor repairs to vehicles may be made only with the approval of a Corral Farm supervisor at a County-designated location. Otherwise, vehicles may not be repaired or abandoned at the facility, and will be towed at owner's expense.

Fauquier County assumes no liability for abandoned or towed vehicles.

All commercial waste hauling vehicles with materials that could blow out of the vehicle must be covered during transport while at the Corral Farm facility including almost-empty open top containers after dumping. The cover may only be removed at designated areas.

Tractor trailers and other oversized dumping containers are banned from the transfer station.

## Commercial Driver Regulations

Drivers and helpers must remain within 15 feet of their vehicles at all times.

**When on the tipping floor** at the Corral Farm transfer station, commercial drivers and helpers shall wear a reflective safety vest, Type I or II hard hat, and are encouraged to wear safety glasses, gloves and protective footwear. Persons on the transfer station tipping floor without reflective vest and hard hat will be asked to leave the area.

Drivers must enter and exit the scales and tipping floor smoothly to prevent damage to County scales and floors. Aggressive backing/stopping of vehicle and shaking of container to remove contents is forbidden.

Drivers will support the waste inspection process by providing accurate information of the origin and type of delivered waste, and are encouraged to witness the inspection and sign the completed form.

Drivers of trucks with hydraulic or other vehicle-related leaks are responsible to clean up their own incidental spills and remove the residue offsite. If Fauquier County is required to cleanup an incidental or major spill, the truck owner/operator will be subject to all administrative and related expenses.

Drivers may not use cell phones, AM-FM radio, CB, and/or two-way radios while on the scales or tipping floor. Usage at other Corral Farm areas should be conducted without impact to operations and other drivers/vehicles.

Drivers may not use horns onsite except for safety or emergency purposes.

Drivers may set off and turn around self-contained compactors only in designated areas and remain clear of other traffic, and County staff.

Drivers shall not clean out behind the truck's compaction blade on the tipping floor unless approved by County staff when space is available to park the vehicle. Otherwise, cleaning must be performed offsite.

In case of hot loads on a truck, drivers will not dump the load in the transfer station but follow instructions of County staff immediately. In case of hot loads on the tipping floor, the truck will exit the transfer station immediately to allow the load to be pushed outside the building.